CORE MODULE 2

Computer Networking

PRACTICAL

Name : - Prateek Kumar

Registration No :- ADIT22AP00152

NSTI Name : - NSTI Noida

Course :- ADIT (IBM)

Date :- 19-10-2024

Module :- Core Module 2

Practical : - Computer Networking

Requirements/tools :-

i) Hardware: -

i. Working PC with Hard disk installed

ii. Internet connection

ii) Software: -

i. Windows operating system

ii. Cisco packet tracer


Question 2: - Configure a static IP address on a Windows computer. Outline the steps required to complete this task.

Solution: -

Steps:

1. Access Network Settings

- Open Network and Internet Settings:
- Right-click the Network icon (Wi-Fi/Ethernet) located in the System Tray at the bottom-right corner of the desktop.
- Select Open Network & Internet settings from the context menu.




- Navigate to Advanced network settings:
- In the Network & Internet window, scroll down to locate Advanced network settings.



2. Choose the Network Adapter

- Identify the Active Network Adapter:
- In the Network Connections window, identify the network adapter that is currently connected (either Ethernet or Wi-Fi) in our case its Ethernet.





- Open more adapter options:
- click on edit button in more adapter options menu.



3. Access IPv4 Settings


- Locate Internet Protocol Version 4 (TCP/IPv4):
- In the Properties window, scroll through the list of items until you find Internet Protocol Version 4 (TCP/IPv4).
- Select it, then click the Properties button.






4. Configure Static IP Address

- Select Manual IP Configuration:
- In the Internet Protocol Version 4 (TCP/IPv4) Properties window, select the option Use the following IP address to switch from DHCP (automatic) to manual IP assignment.



•Lets check our current IP address using CMD just type


ipconfig



Our current IPv4 Address is 192.168.8.63


subnet mask 255.255.255.0 And accordingly, our subnet mask is 255.255.255.0

- Input the IP Address:
 - IP address: Enter a static IP address 192.168.8.118
 - Default gateway: Enter the gateway IP address 192.168.8.1
 - Subnet mask: Input the correct subnet mask 255.255.255.0




5. Configure DNS Server Addresses

- Manual DNS Configuration:
- Preferred DNS server: Enter the preferred DNS server 8.8.8.8
- Alternate DNS server: Enter the alternate DNS server 8.8.4.4



6. Verify Settings

- Check for Errors:
- Double-check all the inputs to ensure accuracy.
- Apply Settings:
- Click OK to save your settings, then click Close on the adapter's Properties window.



7. Test Network Connection

- Reboot the Adapter (Optional):
- Right-click on the network adapter and select Disable. After a few seconds, right-click and choose Enable.
- Test Connectivity:
- Open Command Prompt (Windows + R, type cmd, press Enter).
- Run: ping 192.168.1.1
- If the ping is successful, the connection is working.

```
Microsoft Windows [Version 10.0.22631.3737]
(c) Microsoft Corporation. All rights reserved.


C:\Users\nayan>ping 192.168.8.1

Pinging 192.168.8.1 with 32 bytes of data:
Reply from 192.168.8.1: bytes=32 time<1ms TTL=64
Reply from 192.168.8.1: bytes=32 time<1ms TTL=64
Reply from 192.168.8.1: bytes=32 time=1ms TTL=64
Reply from 192.168.8.1: bytes=32 time=1ms TTL=64


Ping statistics for 192.168.8.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 1ms, Average = 0ms

C:\Users\nayan>
```

• Again, type ipconfig to check that the new IP has been assigned



Conclusion: We have successfully configured static IP address on a windows computer
Question 3: Set up a basic home network using a router. Describe how to connect multiple devices and ensure they can communicate with each other.
Solution:
Step 1: Open Cisco Packet Tracer Launch the Cisco Packet Tracer application on the computer.
We can see a blank workspace where we can build our network.




Step 2: Add Devices to the Workspace


- **Router**: From the device list at the bottom, select a **Router**. Drag and drop it onto the workspace.
 - let's choose a basic router like the **PT- Router**.



• **PCs (End Devices)**: Select **End Devices** from the bottom toolbar and drag **PCs** onto the workspace. Add at least two **PCs**.




• **Switch (optional)**: If we plan to connect multiple devices, you can add a **Switch** between the router and the devices to distribute the connections.



Step 3: Connect the Devices Using Cables


- To connect the devices, click the Lightning Bolt icon from the bottom toolbar to select the appropriate cables.
 - Connect Router to Switch: Use a copper straight-through cable. Click on the router, choose the FastEthernet port (e.g., FastEthernet 0/0), then click on the switch and select a port (e.g., FastEthernet 0/1).
 - Connect Switch to PCs: Use a copper straight-through cable to connect each PC to the switch. Select the FastEthernet 0 port on the PC and connect it to any available FastEthernet port on the switch.



Step 4: Assign IP Addresses to PCs

- Click on PCO, go to the Desktop tab, and select IP Configuration.
 - Assign an IP address to the PC0 (20.20.20.5).
 - Set the **Subnet Mask** to **255.0.0.0**.
 - Set the **Default Gateway** to the router's IP address (20.20.20.1).


Repeat this process for **PC1**, assigning it a different IP address (20.20.20.6), but using the same default gateway



Step 5: Configure the Router

• Click on the **Router**, go to the Config and click on Fast Ethernet 0/0 and enter the IP address (**20.20.20.2**)

This sets the IP address for the router's interface that connects to the PCs.



Step 6: Verify Connectivity


- To check if the devices can communicate, use the ping command from the PCs:
 - 1. Go to **PCO**, open the **Command Prompt** from the Desktop tab.


2. Type the following command to ping the other PC:

ping 20.20.20.6

we should receive successful ping replies if the connection is established.

• Similarly, ping from **PC1** to **PC0** to ensure both devices can communicate.







Step 7: Save the Network Configuration (Optional)

- If you want to save your network setup for future use:
 - o Click on **File** in the top menu and select **Save As** to save your project.